
Fill Line From Surface
4850L
Outlet
PURIFICATION SYSTEM
Inlet
OUTER ZONE
INNER ZONE
PMTs
Lower Level Drift Elevation at 5060L
Pur. System Return
Pur. System Supply
Recirculation Pumps and Flow Configuration Valves
Flow from Top Manifold
Inner Zone Bottom Manifold Flow
Outer Zone Bottom Manifold Flow
Return manifold used during Vessel Fill
Drainage to DUSEL Facility Dewatering System
Detector Draining
Drainage line for Vessel Leaks
Drainage line for Ground Water