
Fill Line From Surface
4850 L
Outlet
PURIFICATION SYSTEM
Inlet
OUTER ZONE
INNER ZONE
PMTs
Lower Level Drift Elevation
Pur. System Return
Pur. System Supply
Recirculation Pumps and Flow Configuration Valves
Flow from Top Manifold
Inner Zone Bottom Manifold Flow
Outer Zone Bottom Manifold Flow
Return manifold used during Vessel Fill
Drainage Flow to Mine Drain Receptacle
Sump Pumps
Detector Draining
Drainage line for Vessel Leaks, Overflow and Ground Water